



NUBI

USER MANUEL

INTRODUCTION

The NUBI jewellery box contains:
A piece of NUBI digital jewellery
A USB cable




USING YOUR NUBI JEWELLRY

On/Off

Hold your finger down on the tactile zone for 5 seconds

The rectangles in the top-right corner of the screen indicate the battery level

Selecting an image or an animation from the dropdown menu



Move your finger along the tactile zone, from top to bottom or vice versa, until your chosen image or animation is in the centre of the screen.

Click on the tactile zone to validate your choice.

Controlling the brightness



Once an image or animation is selected, the bar indicating the brightness of the screen will appear for several seconds.

To return to the menu, click on the tactile zone.

To change the brightness, click on the top or bottom of tactile zone, to increase or decrease the brightness.

Remove your finger from the tactile zone for several seconds to validate your choice.

NB: The light sensor located on the side of the jewelry will also register the difference between the brightness of the screen and the brightness of the environment which you are in. The purpose of this is to maintain the brightness level that you have chosen, regardless of the levels of the brightness in the places where you wear the jewelry. When you change the brightness of the screen, be careful that your fingers are not in front of the light sensor.

Automatic locking

Once the level of brightness is adjusted, the image or the animation (which had been turned in the direction of the user) is flipped horizontally.

The jewelry is ready to wear and the screen is locked.

To unlock the screen, touch the tactile zone for 5 seconds.

The bar indicating the brightness of the screen will reappear. To return to the menu, click the tactile zone.

CHARGING THE BATTERY

Recharge your jewelry by plugging it using the USB cable provided. 2 hours will charge the battery to 80% and 4 hours will charge it to 100%.

When the battery level is low, the brightness of the screen will slowly diminish until the device eventually turns itself off.

INSTALLING THE NUBI SOFTWARE

The NUBI software enables you to import your own images or animations from your computer to your digital jewelry. When you select an image from one of your folders, it will appear in the Page Setup window. You can then adjust your image to fit the NUBI format (1.5 inches, 128 x128px). Once your image has been adjusted, validate the format and then import it into your jewelry.

Install the NUBI software

Plug the piece of digital jewelry into your computer using the USB cable

Launch the NUBI software